





Assembly Guide

SIM IN A BOX® PLAY

FORESIGHT SPORTS | 2025





(PC may Ship Separately with Launch Monitor)

Unboxed Contents



(PC may Ship Separately with Launch Monitor)

Frame Designations



Connect the Frame Sections as Shown



Turf NOT Included but available for Purchase

5

A

B

5

B

4

4

D











Enclosure



Turf NOT Included but available for Purchase

Fasten the 3 Rear Velcro Straps to the Back Cross Bar



Fasten the 6 Side Velcro Straps to the Back Vertical Poles





Wrap the Top Front of the Enclosure Around the Front Cross Bar



Top Front Enclosure Edge Fully Wrapped



Current View of Back of the Enclosure

Secure Velcro Flaps Around Top Side Bars

Top Left Side Bar Fully Wrapped

Top Left Side Bar Fully Wrapped

Top Right Side Bar Fully Wrapped



Wrap Rear Enclosure Flaps Around Back Cross Bar

Wrap Rear Enclosure Flaps Around Back Cross Bar



Wrap Left Side Wall Enclosure Flaps Around Front Vertical Pole



Front Left Side Wall Enclosure Flap

Secured Flap





Rear Left Side Wall Enclosure Flap

Secured Flap

Pull Bottom Side Flap Under the Bottom Side Frame Section

Secure the Bottom Side Flap to the Velcro Strip

Fully Wrapped Bottom Left Side Flap



Complete the same Flap Wrapping Process on the Right Side

Turf NOT Included but available for Purchase

All Flaps Fully Wrapped





Front Screen

Secure the Edges of the Front Screen to the Inner Side Velcro Strips Sewn into the Enclosure


Bottom Right of Screen



Secure the Screen to the Left Side and Down



The Rear Flaps may need to be Loosened to Help Better Secure the Screen to the Enclosure - They can be Re-secured After

Rear View of Enclosure





Side Nettings will have a LEFT and RIGHT Designation

> This End will Secure to the Sandbags

Secure to this Velcro Strip

Wrap Top Corner Velcro Straps Around Exposed Frame on the Top Side Frame Bars as Shown

Make sure to Secure the Velcro Starting from the Top going Down



Continue to Secure the Side Netting Down the Side Velcro Strip



Fold these Velcro Straps Between the Velcro Binding to provide a clean looking Installation



Turf NOT Included but available for Purchase

Once the Side Netting is Secured to the Outer Wall, Tie the Remaining Corner End to the Sandbag and Pull Forward





Place the Projector and the PC on the PC Cart as Shown

Distance From the Screen to the Back of the PC Cart Should be Approximately 17 Feet

17'

Turf NOT Included but available for Purchase